



Ford Transit Custom L1 (2933) Ford Transit Custom L2 (3300) **kit. 6 pz.** (2012 →)

ISTRUZIONI DI MONTAGGIO
NOTICE DE MONTAGE
MONTAGEANWEISUNGEN
ASSEMBLY INSTRUCTIONS
INSTRUCCIONES DE MONTAJE
MONTAGE INSTRUCTIES
INSTRUÇÕES PARA A MONTAGEM
WSKAZOWKI MÓNTAZA
MONT`ZNĚ N`VOD
SMER POKONCĚN



Art.
17424400

FABBRI PORTATUTTO SRL Loc. Penisola, 20A
61026 Piandimeleto (PU) Italia

Tel. +39 0722 58141 Fax. +39 0722
720017 Email: info@fabbri.info Web:
www.fabbri.info

C.F./ P.IVA:
04122300405 Capitale
Sociale€ 20.000,00 i.v.

- | | | | | | | |
|---|---|--|-------------------|---|---|----|
|  |  | | 5505951000 |  M8x75 mm x2 |  | x1 |
|  |  | | |  M8x85 mm x4 | | |
| 8730 x 6 | 4091044000 x 1 | | |  3049179000 x6 |  8606 x12 | |
|  |  | | |  Ø 8 x 16 x6 | | |
| 4091045000 x 4 | F20355A10 x 2 | | |  F20860010 x6 |  M8x45 mm x6 | |
| | | | |  F29240264 x6 | | |
| | | | |  | | |
| | | | | |  M8 x1 | x6 |

